# biamp.


#### **BIAMP UCC-LENOVO TSC INSTALL GUIDE**





BIAMP UCC-LENOVO TSC - MTR

BIAMP UCC-LENOVO TSC - ZOOM

#### IN THE BOX









Core device x 1
Controller x 1
Tiny screws x 2
Medium screws x 4
Larger screws - x 4
Drywall anchors - x 4
Mounting brackets x 4
Power cord x 1
Cord for controller x 1


## **Wall-Mount Option**




#### Wall-Mount Continued




## Wall-Mount Option Continued




#### **Under-Table Mount Option**




Under-Table Mount Option Continued




Under-Table Mount Option Continued




## **Touch Screen - Tabletop**






## **GET STARTED**

#### **Connections**







#### **CONTACT US**

Email: <a href="mailto:support@biamp.com">support@biamp.com</a>

Web: <a href="mailto:support.biamp.com">support.biamp.com</a>

 $\textbf{Warranty:}\ \underline{\textbf{biamp.com/legal/warranty-information}}$ 

Safety & Compliance: <u>biamp.com/compliance biamp.com/legal/warranty-information</u>



